BAM24.PL - SPECYFIKACJA TECHNICZNA & BHP

Zbiorcza Karta Produktu i Instrukcja Bezpieczeństwa / Product Data Sheet & Safety Instructions

1. ZBIORCZA KARTA PRODUKTU — KIESZENIE MONTAŻOWE TABLIC

Profesjonalne stalowe uchwyty (kieszenie) montażowe przeznaczone do stabilnego mocowania tablic wyróżniających, ostrzegawczych, informacyjnych oraz wkładów oznakowania ADR na pojazdach ciężarowych, naczepach, cysternach i maszynach budowlanych.

Symbol	Kod EAN	Wymiary tablicy	Cechy / Zastosowanie
TWY083	5902315109681	120 x 300 mm (12x30 cm)	Przykręcana; tablice wyróżniające, tablice gabarytowe naczep
TWY129	5902315127807	250 x 250 mm (25x25 cm)	Przykręcana; kwadratowe tablice ostrzegawcze i informacyjne
TWY124	5902315113183	300 x 300 mm (30x30 cm)	Przykręcana; duże kwadratowe tablice odpadowe (np. typu A), gabaryty
TWY015	5902315103672	300 x 400 mm (30x40 cm)	Przykręcana; prostokątne tablice ostrzegawcze, tablice ADR
TWY093	5902315126657	400 x 300 mm (40x30 cm)	Przykręcana; dedykowana do wymiennych wkładów liczbowych ADR (12,5x8 cm)

2. INSTRUKCJA BEZPIECZEŃSTWA I MONTAŻU (PL)

2.1 Zastosowanie i Przeznaczenie

- Kieszenie montażowe serii TWY służą wyłącznie do instalacji sztywnych tablic informacyjnych i ostrzegawczych na zewnętrznych elementach konstrukcyjnych pojazdów mechanicznych i naczep.
- Model TWY093 przeznaczony jest do przewozu dedykowanych wkładów cyfrowych systemu ADR i wymaga kontroli blokady wkładów przed rozpoczęciem jazdy.

2.2 Instrukcja Montażu

- Montaż należy przeprowadzić wyłącznie metodą mechaniczną (poprzez przykręcenie śrubami) z wykorzystaniem fabrycznych otworów montażowych kieszeni.
- Zabrania się modyfikowania konstrukcji ramki poprzez nawiercanie dodatkowych otworów, co może osłabić jej sztywność.
- Kieszeń należy mocować do stabilnych, płaskich i sztywnych elementów podwozia lub nadwozia pojazdu, stosując śruby o odpowiedniej klasie wytrzymałości wraz z podkładkami zabezpieczającymi przed samoczynnym odkręceniem (np. nakrętki samokontrujące).

2.3 Zasady Bezpieczeństwa i Eksploatacji

- Przed każdym wyruszeniem w trasę (oraz podczas obowiązkowych postojów) kierowca zobowiązany jest do wizualnej kontroli stanu technicznego kieszeni oraz stabilności osadzenia w niej tablicy/wkładów.
- W przypadku stwierdzenia pęknięć, głębokiej korozji, odkształceń mechanicznych konstrukcji lub obluzowania śrub montażowych, kieszeń należy niezwłocznie dokręcić lub wymienić na nową.
- Podczas wsuwania tablicy lub wkładów wymiennych należy upewnić się, że zostały one wprowadzone do końca prowadnicy i są w pełni zabezpieczone przed wysunięciem na skutek pędu powietrza oraz drgań.
- Uchwyty należy utrzymywać w czystości — nagromadzone błoto, lód lub zanieczyszczenia drogowe mogą zablokować odpływ wilgoci i utrudnić wymianę tablic.

3. COLLECTIVE PRODUCT DATA SHEET — BRACKETS FOR NOTICE PLATES

Professional steel mounting brackets (pockets) designed for stable and secure installation of long vehicle plaques, warning boards, information plates, and interchangeable ADR code panels on trucks, trailers, semi-trailers, tankers, and construction machinery.

Symbol	EAN Code	Plate Dimensions	Features / Application
TWY083	5902315109681	120 x 300 mm (12x30 cm)	Screw-on; marking plates, long vehicle markers, trailer plates
TWY129	5902315127807	250 x 250 mm (25x25 cm)	Screw-on; square warning plates and informative signage
TWY124	5902315113183	300 x 300 mm (30x30 cm)	Screw-on; large square waste boards (e.g., 'A' plaques), oversized cargo panels
TWY015	5902315103672	300 x 400 mm (30x40 cm)	Screw-on; rectangular warning signs, hazards boards, ADR plates
TWY093	5902315126657	400 x 300 mm (40x30 cm)	Screw-on; specialized for interchangeable ADR numerical inserts (12.5x8 cm)

4. SAFETY AND INSTALLATION MANUAL (EN)

4.1 Intended Use and Application

- The TWY series mounting brackets are designed exclusively for installing rigid notice, hazard, and informative panels onto the external structural elements of commercial motor vehicles and trailers.
- Model TWY093 is specifically configured for interchangeable ADR numerical panels and requires active verification of panel locking mechanisms prior to vehicle operation.

4.2 Installation Guidelines

- The bracket must be mounted strictly via mechanical fasting (using screws/bolts) through the pre-drilled factory installation holes.
- Modifying the structural framework of the bracket by drilling additional custom holes is forbidden, as it compromises structural integrity.
- Secure the bracket to rigid, flat, and structurally sound vehicle bodywork or chassis members. Utilize appropriately rated bolts paired with self-locking nuts (e.g., nyloc nuts) to prevent vibration-induced loosening.

4.3 Operational Safety & Maintenance

- Before commencing any journey (and during mandatory transit rest periods), the driver must visually inspect the bracket's structural state and ensure the insert panel is locked and secure.
- If any structural cracks, severe oxidation/corrosion, mechanical distortion, or loose fasteners are detected, the bracket must be instantly tightened or replaced.
- When sliding in a plate or interchangeable number digits, ensure they are pushed fully to the base of the tracks and firmly caught by the safety retention lip to prevent them from being dislodged by heavy wind currents or highway vibrations.
- Keep the brackets clean. Accumulated debris, road mud, or ice must be routinely removed to prevent drainage blockage and allow smooth panel interchangeability.